

PALFINGER



LIFTGATES

ILM *plus* – Series

Troubleshooting: ILM Medium Duty Railgate Lift

<u>Table of content:</u>	<u>Page</u>
1) Gate overview	2
2) Pump and Motor Setup overview	3
3) Controller Identification Overview	4
4) Chain routing (Standard ILM+)	5
5) Chain routing (Above floor ILM+)	6
6) Gate does not opening up.....	7
7) Gate is not lowering down	8
8) Gate is not raising up.....	9
9) Gate is not closing	10
10) Electrical Diagram Manual Closing	11
11) Hydraulic Schematic Manual Closing	12
12) Hydraulic Schematic MC Lift Function	13
13) Hydraulic Schematic MC Lower Function	14
14) Electrical Diagram Power Closing.....	15
15) Hydraulic Schematic Power Close	16
16) Hydraulic Schematic PC Lift Function	17
17) Hydraulic Schematic PC Open Function	18
18) Hydraulic Schematic PC Lower Function	19
19) Hydraulic Schematic PC Close Function	20
20) Platform not lowing down Test	21
21) Check ground on solenoid valves.....	22
22) Testing solenoid valves and cables	23
23) Pump pressure adjustment	24
24) Gate chattering or sticking in rails Inspection Steps.25,26,27,28.	
25) Palfinger Technical Support & Parts Contact list	29

Tools needed:

- 1.) Voltmeter
- 2.) Test light
- 3.) 8" jumper cable (16ga. or smaller)
- 4.) Philips Screw driver
- 5.) 13mm (1/2") wrench

*****MAKE SURE YOUR BATTERIES ARE FULLY CHARGED AND IN GOOD CONDITION*****


Always use CAUTION and allow SAFE distance from moving parts

Practice SAFETY, using common sense and good judgment

Rev-07272022 P1





Gate overview



Pump and Motor Setup Overview

ILM *plus*
Series



Hydraulic Fluid Installed From Factory	
Property	HYDREX MV ARCTIC 15
Start Up Temperature	<50°C / -58°F
Operating Temperature	-45°C to +23°C / -49°F to 73°F
Pour Point	-57°C / -71°F
Flash Point	128°C / 262°F
Density 15°C (59°F). kg/L	0.834
Viscosity:	
cSt @ 40°C/SUV @ 100°F	13.0 / 69.7
cSt @ 100°C/SUV @ 210°F	4.95 / 42.5
cP @ -50°C (-58°F)	1,310

Alternative Fluids	
Temperature Range	Fluid Brand
30° TO 150°F	EXXON UNIVIS J26
	MOBIL DTE 13M
	CHEVRON AW MV32
	ROSEMEAD MV 150 (32)
-50° TO 150°	MOBILE DTE 11
	SHELL AERO FLUID 4/41
	SHELL TELLUS 15
Extreme Cold Temperature	MIL H5606 (Military Spec.)

Controller Identification & Operation Overview




ILM *plus* Series

Power Open and Close will have three button controller




Diode

Inside Remote Schematic






Manual Open and Close will have two button controller




Diode


Inside Remote Schematic




Chain Routing – Standard ILM+



Rear View





Left Side



Right Side

Chain Routing – Above Floor ILM+





1) GATE DOES NOT OPEN UP


a) Initial Checks

- Check Cab Switch is "ON" (Optional)
- Check that Circuit Breaker at battery box has not been tripped
- Check that 15 amp fuse at Motor Solenoid is ok
- Check for shorts, ground faults or open circuits, e.g., power lines connected to the ground or a broken cable or connection
- Check batteries. Batteries should be fully charged and in good condition
- Check voltage - minimum 10 volts at motor when closing or up function is engaged for 10 sec with gate in stored position.

b) Platform is not opening up

- Check if both valves on cylinder are energized.
- If not, check power supply to switches and signal line to valves while activating open function
- Valves are energized – check grounding of valves
- Valves are energized, but Platform still does not open
- Check coil for damage and magnetic function
- Check Gas Shocks on side of platform for damage or seized
- Check open /close cylinder for damage or leaks

2) GATE IS NOT LOWERING DOWN




ILM *plus*
Series

a) Initial Checks

- Check Cab Switch is "ON" (Optional)
- Check that Circuit Breaker at battery box has not been tripped
- Check that 15 amp fuse at Motor Solenoid is ok
- Check for shorts, ground faults or open circuits, e.g., power lines connected to the ground or a broken cable or connection
- Check batteries. Batteries should be fully charged and in good conditions
- Check voltage - minimum 10 volts at motor while activating the UP function with gate in upper position

b) Platform is not lowering down

- Raise gate up just under pump and motor mounting plate remove hydraulic line at pump and remove vent cap on reservoir and place line inside hole for vent and press down button on controller (first making sure all obstacle's are clear and operator is safely clear) If gate lowers with this test then problem is in pump assembly, remove and replace pump and motor assembly.(for this test see illustration on page 13)
- Check if Lift/Lower valve on cylinder is energized.
- If not, check power supply to up/down switch and signal line to Lift/Lower valve while activating lowering function (check for voltage while activating function)
- Valve is energized – check grounding of valve and make sure, (see pictures on page 14) valve is shifted over (hear click)
- Valve is energized, but Platform still does not lower down
- Check if open/close valve is energized – it should NOT be energized.
- Check if flow control valve is contaminated and/or cylinder is damaged



3) GATE IS NOT RAISING UP

a) Initial Checks


- Check Cab Switch is "ON"(Optional)
- Check that Circuit Breaker at battery box has not been tripped
- Check that 15 amp fuse at Motor Solenoid is ok
- Check for shorts, ground faults or open circuits, e.g., power lines connected to the ground or a broken cable or connection
- Check batteries. Batteries should be fully charged and in good condition
- Check voltage - minimum 10 volts at motor after 10 sec holding the switch for closing function. (Deadhead the gate in actual position)

b) Motor does not run

- Check power supply to up/down switch and for voltage at signal line to motor solenoid while activating up function
- Check motor solenoid. If it is getting power (small connector at solenoid has voltage) but you do not hear a click, you should change the motor solenoid.
- You hear it click - check if the motor gets power. If yes, check the motor of correct function.

c) Motor runs but platform does not raise

- Check lift cylinder for damage or chain for broken chain links. (See drawings page 15 & 16)



**ILM *plus*
Series**

4) GATE IS NOT CLOSING

a) Initial Checks

- Check Cab Switch is "ON"(Optional)
- Check that Circuit Breaker at battery box not been tripped
- Check that 15 amp fuse at Motor Solenoid is ok
- Check for shorts, ground faults or open circuits, e.g., power lines connected to the ground or a broken cable or connection
- Check batteries. Batteries should be fully charged and in good condition
- Check voltage - minimum 10 volts at motor at while holding the up function for 10 seconds (Deadhead)


b) Motor is not running

- Check power supply to open/close and up/down switch and for voltage at motor solenoid and open/close valve while activating up function
- Check motor solenoid. If it is getting power but you do not hear click, you should change the motor solenoid.
- You hear it click, check if the motor gets power. If yes, check the motor of correct function.

d) Motor is running, but platform does not close


- Check for power at open/close valve
- Check cylinder for leaking, loose fittings or contaminated restrictor
- Check the hydraulic oil level, low level oil in the reservoir – fill up and activate closing function

Wiring Diagram (Manual Closing)



Hydraulic Schematic (Manual Closing)

ILM *plus*
Series



Hydraulic Schematic (Manual Closing)


ILM *plus*
Series

Lift Function

Green = 12 Volt Power Active

Red = High Pressure

Blue = Low Pressure



Hydraulic Schematic (Manual Closing)


ILM *plus*
Series

Lower Function

Green = 12 Volt Power Active

Red = High Pressure


Blue = Low Pressure



Lowering Function
S1 Valve


Wiring Diagram (Power Closing)

ILM *plus*
Series



Hydraulic Schematic (Power Closing)

ILM *plus*
Series



Hydraulic Schematic (Power Closing)



Lower Function

ILM *plus*
Series

Green = 12 Volt Selected

Red = High Pressure

Blue = Low Pressure



Hydraulic Schematic (Power Closing)



ILM *plus*
Series

Open Function


Green = 12 Volt Selected

Red = High Pressure

Blue = Low Pressure



Open Function
S2 Valve





Hydraulic Schematic (Power Closing)

Lift Function

ILM *plus*
Series

Green = 12 Volt Selected
Red = High Pressure
Blue = Low Pressure





Hydraulic Schematic (Power Closing)

Close Function

ILM *plus*
Series

Green = 12 Volt Selected
Red = High Pressure
Blue = Low Pressure




Platform is not lowering down

Remove hydraulic line from pump and motor and remove vent cap and put the hydraulic line in the tank vent hole and push the down button on controller, if gate goes down problem is in the pump and you need to replace pump and motor, If gate still doesn't go down the problem is not in the pump or motor and other troubleshooting needs to be done to determine if the problems are in the raise and lower valve at the end of the cylinder or in the runners in the columns.

Main hydraulic line


Vent Cap



Check grounds on valves


Check ground screw at solenoid bracket if loose

Then its recommend removing ground from solenoid bracket
And install 5/16 X 1/2 course thread bolt in side of pump block marked GRD



Controller fused connection at solenoid

15 amp fuse for controller power



Power Cable to Solenoid Coil Test

Check for broken power wire in solenoid cable:

- Unplug connector at valve.
- Set multimeter to read DC voltage.
- Put positive lead of multimeter in plug.
- Put negative lead of multimeter in other hole of plug.
- Activate down or close function on gate.
- Preferred reading should be 10V or higher.



Release Valve Coil Test

If one valve on cylinders are not opening up, low voltage may be the cause. A *minimum* of 10 V is necessary to properly energize each of the solenoid coils.

If the minimum voltage is present at both coils, the coil may not be generating the magnetism needed to open the Release valve.

How to check coils for resistance

Multimeter set OHM function.

Place test leads on coil nodes.

Reading shows 5.5 to 7.0 Ω → Coil is good

Reading shows 0 Ω → Coil is shorted out

Reading shows Overload → Coil is destroyed by burn or physical damage



Pump Pressure adjustment

The pressure on the pump is set at the factory and normally no adjustment is needed. If you feel adjustment is necessary please contact Palfinger Field Technical support person in your area which will be listed on last page of this document before proceeding with adjustment.

Tools required for adjustment
13 mm wrench
¼ Allen wrench
5/32 Allen wrench




Palfinger Part required for gauge connections
1- HYD gauge PD-3121327
1- Adaptor fitting PD-312329
1- Elbow fitting PD-75082871

Removing adjustment cap nut
with 13 mm wrench



Adjustment 5/32 Allen wrench



Raise platform until secure in stored position with safety latch down. Loosen allen wrench one turn Counter Clockwise while motor running, tighten clockwise back one turn to flush. Tighten 1/4-1/2 turn more Clockwise to increase PSI to lift load

Gate chattering or sticking in columns Inspection Steps

Step 1.

Check rails are square and parallel in X,Y, and Z axis.
Welded to truck correctly.
(see Installation Manual page 19).

8.2 Check Liftgate Dimensions

Steps:

1. Check Dimensions: Inspect liftgate to be certain it is square and parallel. Use a 3 ft carpenters square. Verify columns are 90 degrees to sill or body.
2. Use "Dim A" and "Dim B" to verify columns are parallel.
3. Use "Dim C" and "Dim D" to verify columns are square.

NOTICE

DO NOT WELD until all dimensions are checked and rechecked after each positioning adjustment.




Figure 8-2: Liftgate Dimensions

Step 2. Check Rails for items listed below

- Rails are not damaged, crushed, or pulled open.
- Inside of rails are clean and free of any grease or non-approved lubricants.
- Inside of rails are smooth and free of any rust, pitting, paint overspray, or weld spatter full length.
- Runners are straight, plastic pads in place, clean, not sticky, not burnt from welding during install.
- Bottoms of rails, if cut, free of slag, and burrs, and ground off smooth with 30° chamfer.

Lift gate chattering or sticking in columns


Inspection Steps

ILM *plus*
Series

Step 3. Check Chains and Sprockets

- Roller chains are adjusted so deck is 1/8" above floor , left and right sides.
- Roller chains have even tension left and right while cycling unit, jam nuts are tight on adjusting anchors.
- AF sprocket boxes are square and parallel to columns.
- Deck support chains are adjusted for even tension left and right sides.
- Sprockets should show signs on break-in grease and roll freely, this includes AF sprockets.
- Sprockets and pins are checked for proper fit. (No sloppy sprockets, no broken teeth)
- Roller chains are free of binding and not seized. Check entire length.

Adjustment points for drive chains



Lift gate chattering or sticking in columns Inspection Steps

ILM *plus*
Series

Step 4. Check that Gate is lubricated per Installation manual

When kept properly lubricated, the PALFINGER ILM liftgate will ensure long lasting usage. Therefore, the liftgate should be lubricated once every 3- months. Average ILM plus use is considered 15 cycles per day or 1200 cycles/3-months. Lubricate more frequently if the lift gate is heavily used or whenever the pivot points appear to be dry.

CAUTION

DO NOT GREASE the “Slider Bearings” or “Columns” or “Runners”, as this will **VOID** your **WARRANTY** on the slide bearings.

Column Lubrication: The columns are designed to run DRY and this is what Palfinger recommends first. However, in some wet or dirty environments, the columns may require periodic lubrication. The schedule will vary based on cycles, load, and environment. We recommend motor oil, 0W20, administered via a machinist style oil can. Don't over do it, a little goes a long way, two or three squirts on to slide surfaces will last months in most cases,


Deck: There are 2 grease fittings to maintain, left and right main pivots,

Power Closing: There are 2 grease fittings to maintain, upper & lower cylinder pivot points.

Manual Closing Gates: Use a light penetrating oil on closing aids; left & right side, upper & lower gas spring mounting points, Page 22.

Deck support chains: Use a light penetrating oil on chain anchors; left & right side,

Lift roller chain: Under normal use and conditions, the lifting roller chain will require minimal lubrication or maintenance as it is impregnated with good quality grease and only makes contact with Polymer sprockets. In extreme wet or dirty environments, should roller chain show signs of drying or rust, lubricate with a good quality motor oil or listed above for columns,




- Grease fitting, 2 for deck, 2 for power closing.



Hydraulic oil level in the power pack tank 2" to the top with deck on the ground.
(see Alternative Fluids chart for recommended Hydraulic oils on Page 3.)



- Deck support chains and optional Cart Stops (use light penetrating oil)



-Columns (optional) use 0W20 motor oil . (Never use GREASE of any kind.)



LIFTGATES

TECHNICAL SUPPORT, SERVICE & PARTS CONTACTS

EAST COAST - Trenton, NJ - 7:00am to 4:00pm ET,
Monday thru Friday

Ben Styer – Parts Asst. / Technical Support

609-587-4200 ext. 126

b.styer@palfinger.com

James Ross – Parts Asst.

609-587-4200 ext. 129

j.ross@palfinger.com

Sean Gettler – Parts Supervisor

609-587-4200 ext. 128

s.gettler@palfinger.com

Bob Hennessee – General Manager

609-587-4200 ext. 125

r.hennessee@palfinger.com

WEST COAST - Cerritos, CA - 8:00am to 5:00pm
PT, Monday thru Friday

Jorge Gallardo – Asst. Tech Support and Warranty
Manager

562-252-0407

j.gallardo@palfinger.com

Rey Rodriguez – Parts Asst.

562-252-0410

j.rodriguez@palfinger.com

Rick Perez- Parts Asst.

562-252-0445

Craig Lopshire – After Sales Manager, West Coast

562-252-0406

c.lopschire@palfinger.com

FIELD TECHNICAL SUPPORT

David Reichel – National Technical Service Director, 607-427-0089 cell

d.reichel@palfinger.com

Pat Strack– Technical Service Manager, Eastern Region, 609-649-9930 cell

p.strack@palfinger.com

Ricky Richardson – Technical Service Manager, Southern Region, 562-202-0172 cell

r.richardson@palfinger.com